




Thank you for choosing Sunnydaze Decor. If you have any questions, comments or concerns please feel free to contact us by phone at: **888-881-4668**, by email: customerservice@serenityhealth.com, or you could also email us via our contact us page at: www.SerenityHealth.com/contact_us.php.

We stand behind our brand and the quality of the items we sell. We will send new parts, or replace products at our discretion within the one year warranty period. Before we can help, you will need to provide proof of purchase with the date of purchase and photos of the defective merchandise. We will use the photos to determine the cause of defect and for future quality control.

CLOSE GENTLY




How to Take Down

CAUTION:

Attempting to erect this canopy in windy conditions may be hazardous and could result in injury and or damage to the product.

1. Remove any leg stakes and ropes, undo the hook and loop tabs of the top cover from around the frame.
 2. You and your partner should each lift up two adjacent outer legs slightly, depress the snap button and push the telescopic inner legs into the outer legs. Repeat for the remaining two legs.
 3. Release the slider at all four corners by a slight upward pressure with one hand while depressing the snap button to release the slider with the other. Push slider down past the snap button.
 4. Each partner should grasp the top of the diamond (see diagram) on opposite sides and slightly lift up. Shake the canopy a little. Pull hands apart while stepping towards your partner until the unit is three quarters closed.
 5. Grasp the two outer legs. Slightly lift off the ground and push together to fully close.
- BE CAREFUL NOT TO PINCH FINGERS. DO NOT PUSH HARD.**
6. Finally having made sure the canopy fabric is completely dry, return your fold canopy to its storage bag.

OPEN GENTLY



Parts Included:

- Assembled Shelter Frame
- Fabric Top
- Storage Bag
- 8 Stakes
- 4-10ft Ropes

How to Set Up

Follow these instructions carefully to avoid pinching your hands or fingers in any of the moving parts as the frame opens and closes. Setting up the canopy may require two people.

1. Place canopy in the center of an open area. Remove the carrying bag and stand the fold up frame on its feet. With a partner on the opposite side, grasp two outer legs, slightly lift the frame off the ground and take a step backwards, stopping at full (outstretched arm's length).
2. Each partner should grasp the top and bottom of the diamond formed by the side supports on opposite sides and push hands together while stepping backwards until the canopy frame is fully opened. Be careful not to pinch your fingers or to pull backwards too hard as this will result in the side supports bending.
3. Engage the slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand (see diagram 3). A snap button will engage in the locating hole. Repeat this operation on the remaining three legs.
4. Place the fabric over the top of the frame. Use the hook and loop straps to secure each corner of the cover to upper portion of each leg. Attach the hook and loop straps tabs, located on the underside of the top cover around the frame struts.
5. You and your partner should each place a foot on the foot plate of the bottom of adjacent legs and lift up the leg, sliding the inner leg out until the snap button locks in the locating hole. Repeat this operation for the other two legs (see diagram 4)
6. To help keep the canopy secure the included ropes and stakes can be used. The rope can be tied to a loop on the upper outside corner of the canopy fabric. The other end can then be tied securely to a stake and inserted into the ground, repeat for each leg.