

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion, within the one-year warranty period. Proof of purchase, with the date of purchase as well as photos of the defective merchandise, must be provided. If you have any questions, comments or concerns please feel free to contact us by phone at: **888-881-4668**. You may also contact us by email: customerservice@serenityhealth.com, or via our webpage at: www.serenityhealth.com/contact-us/



NEON LED DOUBLE-SIDED REINDEER

TLH-374

Parts:

- ELECTRICAL CORD PLUGIN/TRANSFORMER
- DOUBLE-SIDED REINDEER
- 4 STEEL GROUND STAKES
- ***LED ROPE LIGHTS- HAVE NON-REPLACEABLE BULBS**

Assembly:

1. Connect the electrical cord plugin to the transformer
2. For a secure fit tighten the black cap connecting the 2-pin power supply connectors
3. Plug into electrical power outlet
4. Position safely outdoors or indoors as a window ornament

WARNING

- Do not connect this light set to any other light chain
- Do not expose lights to direct heat or flame
- Do not connect the light chain to the power supply while still in the packaging
- The power cable cannot be replaced. If the cable is damaged the set can no longer be used
- Avoid damaging the wiring kit. If the flex or wiring becomes damaged refrain from using the light set
- Do not allow the lights to stand in water or place in a location where water is likely to pool
- Disconnect from power supply when not in use
- Do not remove non-replaceable bulbs
- It is normal for the transformer to become warm during use
- Do not connect the light chain to the power supply directly only use the transformer supplied or one of equivalent rated voltage and wattage

